Most shipping companies use "dimensional weight" to calculate shipping costs, not the actual weight of the item. The Shipping Weight columns reflect dimension weight calculations and should be used to estimate costs. Actual weights are included for reference.

Model Number	Number of Pieces	Dimensions (L x W x H,)	US Shipping Weight (Pounds)	Int'l Shipping Weight (Ibs / kg)	Actual Weight (Pounds)	Actual Weight (Kilograms)
Q-Series Libraries						
Q8 w/ 1 LTO Drive	1	39 x 23 x 9	41	41/ 19	41	19
Q24 w/1 LTO Drive	1	39 x 23 x 11	54	54 / 25	54	25
Q40 Base w/1 LTO Drive	1	46 x 27 x 13	72	72 / 33	72	33
Q40 Expansion	1	46 x 27 x 13	52	52 / 24	52	24
Q48 w/1 LTO Drive	1	39 x 23 x 14	65	65 / 30	65	30
Q80 Base w/1 LTO Drive←	1	43 x 27 x 24	127	127 / 58	127	58
Q80 Expansion ←	1	43 x 27 x 24	110	110	110	50
Q-Series LTO Drive	1	15 x 13 x 7	7	7/3	7	3

← These models are attached to pallets and the Width and Depth dimensions correspond to the edges of the pallet.

↑ All weights include all drives that the model can hold. Drives are shipped in the accessory box in some models.